



## **BATTERY & POWER SUPPLY DISPOSAL AND ORDERING INFORMATION**

**CAUTION:** To reduce the risk of fire or injury, read and follow these instructions:

1. Use only the designated battery pack for the cordless handset and power adapter for the base. The battery and power supply required for this telephone is uniquely designed for this product. Do not use other batteries or power supplies. To order additional battery(ies) or power supply(ies), contact your regional PriorityCare department.
2. Do not dispose of the battery(ies) in a fire. The cell may explode. Check with the your local codes for special disposal instructions.
3. Do not open or mutilate the battery(ies). Released electrolyte is corrosive and may cause damage to the eyes or skin. It may be toxic if swallowed.
4. Exercise care in handling batteries in order not to short the battery with conducting materials such as rings, bracelets and keys. The battery or conductor may overheat and cause burns.
5. Do not attempt to independently recharge the battery(ies) provided with or identified for use with this product. The batteries may leak corrosive electrolyte or explode.
6. Do not attempt to rejuvenate the battery(ies) provided with or identified for use with this product by heating them. Sudden release of the battery electrolyte may occur causing burns or irritation to the eyes or skin.
7. When replacing the batteries, all batteries should be replaced at the same time. Mixing fresh and discharged batteries could increase internal cell pressure and rupture the discharged battery(ies). (Applies to products employing more than one separately replaceable primary battery).
8. When inserting batteries into this product, the proper polarity or direction must be observed. Reverse insertion of batteries can cause charging, and that may result in leakage or explosion (applies to product employing more than one separately replaceable primary battery).
9. Remove the batteries from this product if the product will not be used for a long period of time (several months or more) since during this time the battery could leak in the product.
10. Discard dead batteries as soon as possible since dead batteries are more likely to leak in a product.
11. Do not store this product, or the batteries provide with or identified for use with this product in high-temperature areas. Batteries that are stored in a freezer or refrigerator for the purpose of extending the shelf life should be protected from condensation during storage and defrosting. Batteries should be stabilized at room temperature prior to use after cold storage.

[customerservice@telematrix.net](mailto:customerservice@telematrix.net)

**PLEASE SAVE THESE INSTRUCTIONS**

[customerservice@telematrix.net](mailto:customerservice@telematrix.net)    [www.telematrix.net](http://www.telematrix.net)