

**PROGRAMMING  
STEPS:**

Press STORE Key

**MENU DISPLAYS:**

1. MONTH: 01
2. DAY: 01
3. HOUR: 12AM
4. MINUTE: 00
5. AM=1 PM=2
6. -1- -2- -3-  
ENG FRA ESP
7. VOICE MAIL NO.
8. VM PIN
9. VM PIN WAIT TIME
10. 1-TOUCH VM OFF
11. OUTSIDE LINE PRE
12. LONG DISTANCE  
PREFIX
13. AREA CODE 1
14. AREA CODE 2
15. CALL WAIT ON
16. PAUSE TIME 3.6S
17. FLASH TIME
18. LIVE DIAL PAD OFF
19. SDT ON
20. ALL SETUP OK

# LP550 ADDENDUM

**LP-550 A 7B 5**

Use this Addendum for LP550 telephones with the above version sticker.

## Programming:

**SPECTRUM PLUS™**

Line Powered Caller ID Speakerphone

### Steps in Programming All Functions:

- a. **The phone must be hung up (on hook) to begin programming.**
- b. **Press the STORE key to enter the programming mode.**
- c. **Continue to press STORE key until you arrive at the function you wish to program. (i.e. Press STORE 6 times if you wish to change the display language)**
- d. **Use the digit keys to change or enter new data, while desired item is being displayed.**
- e. **Then press STORE key to save into memory.**
- f. **Press DISC key or continue to press STORE until you get to ALL SETUP OK to exit programming mode. Pressing DISC before STORE key will result in losing that menu's programming.**
- g. **If no key is pressed for 60 sec. or the phone rings while programming the phone will automatically exit programming mode.**

To print a complete manual see [www.telematrix.net](http://www.telematrix.net), then Downloads - User Manuals - click on LP550 under Spectrum Plus.

If you have additional question please contact PriorityCare at: [prioritycare@telematrix.net](mailto:prioritycare@telematrix.net) / +1.719.638.8821

These telephones only operate behind a PBX.

